




# Trader Switch Installation and Operations

## Introduction

Raritan's TraderSwitch allows users to operate a Sun Workstation and a PS/2 PC from a single Sun keyboard and mouse. It is designed to be highly reliable and ergonomically integrated into a modern office environment.

## Installation

1. Connect monitors to the Sun Workstation and the PC.
2. Connect a Sun keyboard and mouse cable to the TraderSwitch keyboard port (A).
3. Connect the Sun keyboard and mouse cable (CTSS20) from TraderSwitch Sun Channel (B) to the Sun Workstation keyboard port.
4. Connect the PC keyboard and mouse cable (CTSP20U) from TraderSwitch PC Channel (C) to the PC keyboard and mouse ports.
5. Power ON first the Sun Workstation, and then the PC.
6. If necessary, connect the optional DC power supply to the TraderSwitch (D).



## Operation

1. Use TraderSwitch front panel buttons to switch between the Sun Workstation and the PC.
  - Push Sun button for Sun Workstation (E)
  - Push PC button for PC (F)
2. Or, use the designated keys as shown on the Sun keyboard to switch between the Sun Workstation (G) and the PC (H).
3. Optionally, you can activate the beeping sound when switching channels.
  - Press either the Sun or the PC button on the TraderSwitch front panel, and hold for at least four seconds.
  - If you hear two beeps, the beeping sound is ON.
  - If you hear one beep, the beeping sound is OFF.

## Specifications

<b>TS2</b>	
<b>Dimensions</b>	10.55" (W) x 7.87" (D) x 1.75" (H) 1.62 kg (3.6 lbs)
<b>Power</b>	Powered by connected computers
<b>Operating Temp.</b>	0–50°C (32–122°F)
<b>Cables</b>	
<b>CTSS20</b>	6.5' cable for Sun KB and mouse
<b>CTSP20U</b>	6.5' cable for PC KB and mouse
<b>Optional DC Adapter</b>	6V/500mA Adapter (DC6500U)
<b>One Year Warranty</b>	



**Raritan Computer, Inc.**  
400 Cottontail Lane  
Somerset, NJ 08873  
U.S.A.  
Tel. 1-732-764-8886  
Fax 1-732-764-8887  
E-mail: sales@raritan.com  
http://www.raritan.com

**Raritan Computer Europe, B.V.**  
Mient 16c,  
2903 LC Capelle A/D IJssel  
The Netherlands  
Tel. 31-10-284-4040  
Fax 31-10-284-4049  
E-mail: sales.europe@raritan.com  
http://www.raritan.com

**Raritan Computer Japan, Inc.**  
Kuga Building 7F, 11-6  
Kuramae 4-chome Taitoo-Ku  
Tokyo 111-0051, Japan  
Tel. 81-3-5833-6360  
Fax 81-3-5833-6336  
Email: sales.japan@raritan.com  
http://www.raritan.com

**Raritan Computer Taiwan, Inc.**  
5F,121,Lane 235,Pao-Chiao Rd,  
Hsin-Tien City,Taipei Hsien  
Taiwan,ROC  
Tel. 886-2-8919-1333  
Fax 886-2-8919-1338  
E-mail:sales.asia@raritan.com  
http://www.raritan.com